

PROPORTIONAL PRESSURE RELIEF AND REDUCING VALVES

Valve model:
RZMO-REB-P RZGO-REB-P AGMZO-REB-P AGRCZO-REB-P

Driver model:
E-RI-REB-P

IDENTIFICATION

Valve identification plates and label

Valve name plate : M
1 : valve code
2 : valve matrix code
3 : valve hydraulic symbol

Pilot valve name plate : N
4 : pilot valve code
5 : pilot valve matrix code
6 : pilot hydraulic symbol

Driver label : L
7 : driver code
8 : driver serial number
9 : factory firmware version

INSTALLATION TOOLS ACCORDING TO VALVE MODEL- not included

Fastening bolts	Wrenches	Screwdriver	Main connectors
socket head screws	for fastening bolts mechanical pilot relief	for air bleeding	std, /Q /Z
see STEP 1 and STEP 3			see STEP 2

PROGRAMMING TOOLS - not included

Software	USB connection KIT	OR	Bluetooth connection KIT
E-SW-BASIC free basic software download from MyAtos at www.atos.com	Cable E-C-SB-USB/M12 Isolator E-A-SB-USB/OPT		Cable E-C-SB-M12/BTH Adapter E-A-SB-USB/BTH

PROGRAMMING SOFTWARE

The software is available in different versions according to the driver's options:

E-SW-BASIC supports	NP (USB)	IL (IO-Link)	PS (Serial)	IR (Infrared)
E-SW-FIELDBUS supports	BC (CANopen)	BP (PROFIBUS DP)	EH (EtherCAT)	EW (POWERLINK)
E-SW-/PQ supports	valves with SP, SF, SL alternated P/Q control			

E-SW-FIELDBUS supports also valves without fieldbus communication; E-SW-/PQ supports also valves without P/Q control

REMARK Atos software is designed for Windows based operative systems - Windows XP SP3 or later

DOWNLOAD AREA

Perform the registration at www.atos.com/en-it/login by filling the form. In MyAtos area, perform login with personal username and password and then press the **Download area electronics** button

Free version of E-SW-BASIC can be downloaded and used by the "FREE Activation Code"

The software remains active for 10 days from the installation date and then it stops until the user inputs the Activation Code

RELATED DOCUMENTATION - www.atos.com - section Catalog on-line

FS900 Operating and maintenance information - tech. table	STARTUP E-SW-BASIC Software startup guide
FS010 RZMO-010 pressure relief, direct - tech. table	STARTUP BLUETOOTH Bluetooth adapter startup guide
FS020 RZGO-010 pressure reducing, direct - tech. table	E-MAN-RI-REB REB - driver operating manual
FS040 AGMZO pressure relief, two stage - tech. table	
FS055 AGRCZO pressure reducing, two stage - tech. table	
FS067 RZMO-030 pressure relief, piloted - tech. table	
FS075 RZGO-033 pressure reducing, piloted - tech. table	
P005 Mounting surfaces - tech. table	
GS500 Programming tools - tech. table	
K800 Electric and electronic connectors - tech. table	

ATTENTION !

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

CONTACT US

Atos spa - Italy - 21018 Sesto Calende www.atos.com support@atos.com

PRODUCTS OVERVIEW

STEP 1: Initial valve assembly.

STEP 2: Mounting the valve to the actuator.

STEP 3: Tightening the fastening bolts.

STEP 4: Final valve assembly and connection.

INSTALLATION			PROGRAMMING
STEP 1	STEP 2	STEP 3	STEP 4
MECHANICAL	ELECTRICAL	HYDRAULICS	SOFTWARE

STEP 1 MECHANICAL

In case of first commissioning, before the valve installation the whole system must be correctly flushed to grant the required cleanliness level

During the flushing operation use on-off or by-pass valves in place of the proportional valve

- remove protection pad **P1** located on the valve bottom face only immediately before installation (do not remove connectors caps)
- check the presence and correct positioning of the seals on valve ports
- verify that valve mounting surface is clean and free from damages or burrs
- verify the correct valve orientation according to the pattern of the relevant mounting interface
- lock the fastening bolts respecting below sequence and tightening torque according to valve model

RZMO-REB / RZGO-REB	AGMZO-REB-10	AGMZO-REB-20	AGMZO-REB-32	AGRCZO-REB-10	AGRCZO-REB-20
Mounting surface layout 4401-03-02-0-05 (RZMO without A and B ports) Valve size ISO 4401: 06	Mounting surface layout 6264-06-09-1-97 Valve size ISO 6264: 10	Mounting surface layout 6264-08-13-1-97 Valve size ISO 6264: 20	Mounting surface layout 6264-10-17-1-97 Valve size ISO 6264: 32	Mounting surface layout 5781-06-07-0-00 Valve size ISO 5781: 10	Mounting surface layout 5781-08-10-0-00 Valve size ISO 5781: 20
Fastening bolts socket head screws n°4 M5x50 class:12.9 wrench 4 mm	Fastening bolts socket head screws n°4 M12x35 class:12.9 wrench 10 mm	Fastening bolts socket head screws n°4 M16x50 class:12.9 wrench 14 mm	Fastening bolts socket head screws n°4 M20x60 class:12.9 wrench 17 mm	Fastening bolts socket head screws n°4 M10x45 class:12.9 wrench 8 mm	Fastening bolts socket head screws n°4 M10x45 class:12.9 wrench 8 mm
Tightening torque: 8 Nm	Tightening torque: 125 Nm	Tightening torque: 300 Nm	Tightening torque: 600 Nm	Tightening torque: 70 Nm	Tightening torque: 70 Nm

STEP 2 ELECTRICAL

This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code

1 Remove main connector cap **P2**

2 Select main connector according to valve code and proceed with wirings operations

7 PIN MAIN CONNECTOR
ZM-7P (metallic)

12 PIN MAIN CONNECTOR
ZM-12P (metallic)

WARNING: remove power supply before any electrical or wiring operations

3 Connect the valve to the system

Standard		/Z option	
A V+	(power supply 24Voc)	1 V+	(power supply 24Voc)
B V0	(power supply 0Voc)	2 V0	(power supply 0Voc)
C AGND	(input 24Voc)	3 ENABLE	(input 24Voc)
D P_INPUT+	(0 ÷ 10Voc / 4 ÷ 20mA)	4 P_INPUT+	(0 ÷ 10Voc / 4 ÷ 20mA)
E INPUT-		5 INPUT-	
F P_MONITOR	(0 ÷ 10Voc / 4 ÷ 20mA)	6 P_MONITOR	(0 ÷ 10Voc / 4 ÷ 20mA)
G EARTH		7 NC	
		8 NC	
		9 VL+	(logic power supply 24Voc)
		10 VL0	(logic power supply 0Voc)
		11 FAULT	(output 24Voc)
		PE	EARTH

NOTE: the use of above metallic connectors is strongly recommended in order to fulfill EMC requirements

WARNING: a safety fuse is required in series to driver power supply - 2,5 A time lag fuse

ELECTRICAL WIRING EXAMPLES

MAIN CONNECTOR - VOLTAGE		MAIN CONNECTOR - CURRENT	
REFERENCE INPUT - DIFFERENTIAL MODE	REFERENCE INPUT - DIFFERENTIAL MODE	REFERENCE INPUT - COMMON MODE	REFERENCE INPUT - COMMON MODE
MONITOR OUTPUT	MONITOR OUTPUT	MONITOR OUTPUT	MONITOR OUTPUT

STEP 3 HYDRAULICS

Air bleeding:

- release 2 or 3 turns the air bleed screw **V**
- cycle the valve at low pressure until the oil leaking from the **V** port is exempted from air bubbles
- lock the air bleed screw **V**

Mechanical pressure limiter setting – only AGMZO and AGRCZO with /P option

For safety reasons the factory setting of the mechanical pilot relief valve is fully unloaded (min pressure).

At the first commissioning it must be set at a value lightly higher than the max pressure regulated with the proportional control, proceeding as follow:

- apply the max reference input signal to the valve's driver. The system pressure will not increase until the mechanical pressure limiter remains unloaded
- release the locknut ②, turn clockwise the adjustment screw ① until the system pressure will increase up to a stable value corresponding to the pressure set-point at max reference input signal
- turn clockwise the adjustment screw ① of additional 1 or 2 turns to ensure that the mechanical pressure limiter remains closed during the proportional valve working, then tighten the locknut ②

Consult tech table **FS900** for general guidelines about component's commissioning

WARNING: To avoid overheating and possible damage of the electronic driver, the valves must be never energized without hydraulic supply to the valve. In case of prolonged pauses of the valve operation during the machine cycle, it is always advisable to switch off or disable the driver (option /Q or /Z)

STEP 4 SOFTWARE


REMARK proportional valves with integral electronics are factory preset with default parameter and ready to use after piping and electrical connections. **Play with parameters is optional, not mandatory!**

PROGRAMMING				PC
4.1	4.2	4.3	4.4	4.5
CONNECTION	CONFIGURATION	SMART TUNING	STORE	BACK UP

4.1 CONNECTION


- In order to access valve parameterization:
 - Install E-SW-BASIC software on PC
 - Insert main connector to the valve and power on with 24Vdc

- Remove USB plastic protection cap **P3** and connect valve to the PC as shown below



- Launch the software using E-SW icon:
 - software does NOT detect valid connection communication is not established, please follow wizard procedure
 - software detects valid connection communication automatically established - valve is ON-LINE see

- Press buttons according the below sequence:
 - a) ON-LINE - Recommended** Wizard procedure for standard connection
 - b) CONNECT TO NP, PS, IR, IL**




NOTE: Bluetooth adapter available! For more info please refer to STARTUP BLUETOOTH guide

REMARK: once removed the USB cable E-C-SB-USB/M12, screw the plastic protection cap **P3** applying the correct tightening torque, in order to preserve valve's IP protection characteristics

4.2 CONFIGURATION


All valves



BiasP positive bias ScaleP positive scale


BIAS AND SCALE

- Bias setting:** supply the input signal equal to 0 bar
- relief valves:** increase the Bias until the pressure starts to increase, then lightly reduce the Bias just to bring back the pressure lightly over the minimum regulated value
 - reducing valves:** increase the Bias until is reached the minimum desired value of starting pressure
- Scale setting:** supply the max input signal; adjust the Scale to obtain the max regulated pressure



RAMPS

- Ramps setting:** select the required ramp configuration and adjust the ramp time to optimize the pressure response according to the system characteristics
- No Ramp:** no ramps selected **Single Ramp:** setup Ramp 1 **Double Ramp:** setup Ramp 1 and 2



WIZARD REFERENCE - E-SW level 2 functionality

Reference input signal is factory preset according to selected valve code, defaults are 0 ÷ 10 Vdc for standard and 4 ÷ 20 mA for /I option. Input signal can be reconfigured via software selecting between voltage and current, browsing to **Reference Analog Range** page:

REMARK: Voltage Standard or Current 4..20 mA buttons do not act on Monitor output signal configuration! For Monitor output signal configuration browse to page **Others - Monitor Outputs**

4.3 SMART TUNING - E-SW level 2 functionality

Smart tuning allows to adjust the valve dynamic response in order to match different performance requirements.

4.4 STORE

- Parameters modifications will be stored into driver permanent memory:
- press **Memory Store** button to access **Driver - Memory Store** window
 - press **Store User** button to store **Valve Parameters**
- WARNING:** During valve parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

4.5 BACK UP

- Parameter modifications will be saved into PC memory:
- press **Save** button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
 - input a valid name into **Description** field and press **Ok** button

TROUBLESHOOTING

- Valve vibration or noise**
- presence of air in the solenoid; perform air bleeding procedure – see STEP 3
- The valve does not follow the reference signal**
- valve is powered off, verify presence of 24 Vdc power supply
 - valve is disabled, verify presence of 24 Vdc on enable pin - only for /Q and /Z options
 - the mechanical pressure limiter interferes with the regulation (AGMZ0 and AGRCZO with /P option) – check the pilot relief valve setting
 - spool sticking (RZMO-030 and RZGO-033) – contact Atos service center
 - wrong pilot/drain configuration (AGMZ0) – check if the pilot/drain configuration of the valve corresponds to the effective system layout
- Pressure instability or vibration**
- select PID4 to operate the valve in open loop:
 - if the instability still persists, check eventual anomalies in the hydraulic circuit as the presence of air
 - if the instability disappears, select an alternative configuration within PID selection 1, 2 or 3 which better matches the application requirements
 - if no one of the above selection fulfills the application, tune P - I - D parameters at E-SW software level 2 to obtain the desired dynamic response
- Software parameters modifications are lost when valve is switched off**
- parameter store operation was not performed, check store procedure – see STEP 4, section 4.4
- Software parameters modifications have no effect on the valve**
- valve is OFF LINE, check connection procedure – see STEP 4, section 4.1
- After the modifications of software parameters the valve does not work properly**
- restore valve factory parameters using 'Restore Factory' button, located in 'Driver - Memory Store' window:
 - during restore, the current to the solenoid(s) will be temporarily switched to off!
 - factory parameters will be applied at next driver restart or after power off-on sequence!